


# Cleaning Dura-Bright® wheels

There is no Alcoa® wheel easier to maintain than a Dura-Bright® wheel.




1.



Allow wheels to cool below 35° C  
Remove nut covers.

2.



Rinse the wheel with water to prevent scratching and erosion.

3.




Mix water with a mild detergent or use undiluted Dura-Bright® Wheel Wash (shake before use).

4.



Clean the wheel with a soft brush for 2 to 5 minutes to achieve the best possible result.

5.



Rinse with water.



Before

After

## Cleaning products for Alcoa® Dura-Bright® wheels

### Dura-Bright® Wheel Wash

- Helps to prevent the build-up of brake dust and oxidation
- No risk of damaging wheels with harsh chemicals
- No need to dilute
- Suitable for all Dura-Bright® generations
- Economic in use

### ALbrush2

- A premium quality brush with a rubber edge to protect wheels from getting damaged during cleaning



For additional information about cleaning and maintenance see section 'Care and Maintenance' within the Service Manual for Alcoa® wheels.



Available from authorized Alcoa® wheels distributors.



Cleaning Alcoa® Dura-Bright® wheels video.




**Howmet Wheel Systems**  
info.wheels@howmet.com  
www.alcoawheelseurope.com

Alcoa® Wheels<sup>1</sup> is a product brand of Howmet Aerospace.  
© 2024 Howmet Aerospace Inc. or a Howmet Aerospace Inc. affiliate.  
1. The "ALCOA" name and geometric symbol are registered trademarks of Alcoa USA Corporation and are licensed to Howmet Aerospace Inc. and its subsidiaries.

Howmet Aerospace reserves the right to change the information in this Cleaning Sheet, including the technical characteristics and designs of Alcoa® wheels. This Cleaning Sheet may not reflect the most recent development and accuracy of the information herein is not guaranteed.

# Cleaning LvL ONE® and Brushed wheels



1. Allow wheels to cool below 35° C. Remove nut covers.



2. Rinse the wheel with water to prevent scratching and erosion; preferably with a high pressure cleaner.



3. Pour a quantity\* of ALclean into a bucket and dilute with 1, 2 or 3 parts of water.




Recommended quantities:  
1. for difficult spots  
2. for medium pollution  
3. for regular use  
4. for frequent use



4. Gently brush ALclean onto the wheel.



5. Rinse with clean water. Repeat these steps if needed.



6. Dry the wheel.

## LvL ONE® wheels



7. Continue by applying a small amount of ALpolish.



8. Spread it evenly over the wheel using a moist cloth and polish the wheel.

## Cleaning Products for Alcoa® LvL ONE® wheels

### ALclean

- Removes oxidation, disk brake dust, salt spray and road grime
- Use for Brushed, Mirror Polished and LvL ONE® finishes

### ALbrush2

- A premium quality brush with a rubber edge to protect wheels from getting damaged during cleaning

### ALpolish

- Restore and maintain the shine of Mirror Polished, LvL ONE® Alcoa® wheels
- Use after ALclean



For additional information about cleaning and maintenance see section 'Care and Maintenance' within the Service Manual for Alcoa® wheels.



Available from authorized Alcoa® wheels distributors.



Cleaning Alcoa® Brushed and LvL ONE® wheels and Polishing LvL ONE® wheels video.